







MAROON



__ **DINNER PLATE Ø 27 cm**5697028
Ø 27 x H 2 cm
4 / 12



__ DESSERT PLATE Ø 21 cm 5697027 Ø 21 x H 2 cm 6 / 24



__ BREAD PLATE Ø 16 cm 5697029 Ø 16 x H 2 cm 6 / 48



__ PLATE Ø 28 cm 5697014 Ø 28 x H 5 cm 2 / 8



__ PLATE Ø 24 cm 5697013 Ø 24 x H 5 cm 2 / 8



__ PLATE Ø 22 cm 5697011 Ø 22 x H 5 cm 4 / 16



__ PLATE Ø 17 cm 5697012 Ø 17 x H 4 cm 4 / 24



__BOWL Ø 20 cm 5697019 Ø 20 x H 9 cm 2 / 8



__ BOWL Ø 17 cm 5697017 Ø 17 x H 6 cm 4 / 16



__ BOWL Ø 15 cm 5697018 Ø 15 x H 8 cm 4 / 16



__ BOWL Ø 13 cm 5697016 Ø 13 x H 6 cm 6 / 24



__ BOWL Ø 8 cm 5697015 Ø 8 x H 6 cm 6 / 48

MAROON



__ DISH Ø 13 cm 5697010 Ø 13 x H 3 cm 6 / 36



__ **DISH Ø 9 cm**5697009
Ø 9 x H 3 cm
6 / 72



__ APERO BOWL Ø 8 cm 5697002 Ø 8 x H 4 cm 12 / 96



__ APERO DISH Ø 0 cm 5697005 14 x H 4 cm 6 / 72



__ TEAPOT Ø 19 cm 5697032 19 x H 11 cm - 750ml 1 / 8



__ TEAPOT Ø 11 cm 5697001 11 x H 7 cm - 330ml 1 / 6



__ PITCHER Ø 13 cm 5697033 13 x H 21 cm - 1650ml 1 / 8



5697008 10 x H 17 cm - 250ml 6 / 24

9



__ APERO DISH Ø 0 cm 5697004 10 x H 3 cm 12 / 96



__ APERO DISH Ø 0 cm 5697003 10 x H 3 cm 12 / 96



__ APERO DISH Ø 0 cm 5697007 9 x H 2 cm 12 / 96



__ APERO DISH Ø 7 cm 5697006 Ø 7 x H 4 cm 12 / 96



5697030 Ø 29 x H 13 cm 1 / 4



__ **SAUCER Ø 14 cm**5697024
Ø 14 x H 2 cm
6 / 48




__ **SAUCER Ø 11 cm**5697023
Ø 11 x H 2 cm
12 / 96



__ SOUP BOWL Ø 13 cm 5697031 Ø 13 x H 8 cm - 500ml 6 / 24



__ MUG Ø 7 cm 5697025 Ø 7 x H 8 cm 6 / 48



MINERAL



__ **DINNER PLATE Ø 27 cm**5699027
Ø 27 x H 2 cm
4 / 12



__ DESSERT PLATE Ø 21 cm 5699028 Ø 21 x H 2 cm 6 / 24



BREAD PLATE Ø 16 cm5699029
Ø 16 x H 2 cm
6 / 48



__ PLATE Ø 28 cm 5699014 Ø 28 x H 5 cm 2 / 8



__ PLATE Ø 24 cm 5699013 Ø 24 x H 5 cm 2 / 8



__ PLATE Ø 22 cm 5699011 Ø 22 x H 5 cm 4 / 16



__ PLATE Ø 17 cm 5699012 Ø 17 x H 4 cm 4 / 24



__ BOWL Ø 20 cm 5699019 Ø 20 x H 9 cm 2 / 8



__BOWL Ø 17 cm 5699017 Ø 17 x H 6 cm 4 / 16



__ BOWL Ø 15 cm 5699018 Ø 15 x H 8 cm 4 / 16



__BOWL Ø 13 cm 5699016 Ø 13 x H 6 cm 6 / 24



__ BOWL Ø 8 cm 5699015 Ø 8 x H 6 cm 6 / 48

MINERAL



__ **DISH Ø 13 cm**5699010
Ø 13 x H 3 cm
6 / 36



__ **DISH Ø 9 cm**5699009
Ø 9 x H 3 cm
6 / 72



12 / 96

__ APERO BOWL Ø 8 cm 5699002 Ø 8 x H 4 cm



__ APERO DISH Ø 0 cm 5699005 14 x H 4 cm

6 / 72



__ COFFEE CUP Ø 8 cm 5699020 Ø 8 x H 7 cm

6/36



__ COFFEE CUP Ø 7 cm
5699022
Ø 7 x H 6 cm
6 / 48



__ ESPRESSOCUP Ø 6 cm 5699021 Ø 6 x H 5 cm 12 / 96



__ MILK JUG Ø 9 cm 5699026 Ø 9 x H 5 cm 6 / 72



__ APERO DISH Ø 0 cm 5699003 10 x H 3 cm 12 / 96



__ APERO DISH Ø 0 cm 5699004 10 x H 3 cm 12 / 96



__ APERO DISH Ø 0 cm 5699007 9 x H 1 cm 12 / 96



__ APERO DISH Ø 7 cm 5699006 Ø 7 x H 4 cm 12 / 96



___ **TEAPOT Ø 19 cm**5699032
19 x H 11 cm - 750ml
1 / 8



__ TEAPOT Ø 11 cm 5699001 11 x H 7 cm - 330ml 1 / 6



__ PITCHER Ø 13 cm 5699033 13 x H 21 cm - 1650ml 1 / 8



COFFEEMAKER Ø 10 cm5699008
10 x H 17 cm - 250ml
6 / 24

13



__ **SAUCER Ø 14 cm**5699024
Ø 14 x H 2 cm

6/48



__ SAUCER Ø 11 cm 5699023 Ø 11 x H 2 cm 12 / 96



__ SOUP BOWL Ø 13 cm 5699031 Ø 13 x H 8 cm - 500ml 6 / 24



__ MUG Ø 7 cm 5699025 Ø 7 x H 8 cm 6 / 48



5699030 Ø 29 x H 13 cm 1 / 4

MUSTARD









5698027 Ø 27 x H 2 cm 4 / 12

__ DESSERT PLATE Ø 21 cm 5698028 Ø 21 x H 2 cm 6 / 24

__ BREAD PLATE Ø 16 cm 5698029 Ø 16 x H 2 cm 6 / 48

__ PLATE Ø 28 cm 5698014 Ø 28 x H 5 cm 2 / 8



__ PLATE Ø 24 cm 5698013 Ø 24 x H 5 cm 2 / 8



__ PLATE Ø 22 cm 5698011 Ø 22 x H 5 cm 4 / 16



__ PLATE Ø 17 cm 5698012 Ø 17 x H 4 cm 4 / 24



__ BOWL Ø 20 cm 5698019 Ø 20 x H 9 cm 2 / 8



__ BOWL Ø 17 cm 5698017 Ø 17 x H 6 cm 4 / 16



__ BOWL Ø 15 cm 5698018 Ø 15 x H 8 cm 4 / 16



__ BOWL Ø 13 cm 5698016 Ø 13 x H 6 cm 6 / 24



__ BOWL Ø 8 cm 5698015 Ø 8 x H 6 cm 6 / 48

MUSTARD



__ **DISH Ø 9 cm**5698009
Ø 9 x H 3 cm
6 / 72



__ **DISH Ø 13 cm**5698010
Ø 13 x H 3 cm
6 / 36



__ APERO BOWL Ø 8 cm 5698002 Ø 8 x H 4 cm

12 / 96



__ APERO DISH Ø 0 cm 5698005 14 x H 4 cm

6 / 72



__ COFFEE CUP Ø 8 cm 5698020 Ø 8 x H 7 cm

6/36



__ COFFEE CUP Ø 7 cm 5698022 Ø 7 x H 6 cm 6 / 48



__ ESPRESSOCUP Ø 6 cm 5698021 Ø 6 x H 5 cm 12 / 96



__ MILK JUG Ø 9 cm 5698026 Ø 9 x H 5 cm 6 / 72



__ APERO DISH Ø 0 cm 5698004 10 x H 3 cm 12 / 96



__ APERO DISH Ø 0 cm 5698003 10 x H 3 cm 12 / 96



__ APERO DISH Ø 0 cm 5698007 9 x H 1 cm 12 / 96



__ APERO DISH Ø 7 cm
5698006
Ø 7 x H 4 cm
12 / 96



___ **TEAPOT Ø 19 cm**5698032
19 x H 11 cm - 750ml
1 / 8



___ TEAPOT Ø 11 cm 5698001 11 x H 7 cm - 330ml 1 / 6



__ PITCHER Ø 13 cm 5698033 13 x H 21 cm - 1650ml 1 / 8



5698008 12 x H 16 cm - 250ml 6 / 24

17



__ **SAUCER Ø 14 cm**5698024
Ø 14 x H 2 cm

6 / 48



__ SAUCER Ø 11 cm 5698023 Ø 11 x H 2 cm 12 / 96



— **SOUP BOWL Ø 13 cm**5698031
Ø 13 x H 8 cm - 500ml
6 / 24



__ MUG Ø 7 cm 5698025 Ø 7 x H 8 cm 6 / 48



__ CAKE PLATE Ø 29 cm 5698030 Ø 29 x H 13 cm 1 / 4



BOGOTA



__ **DINNER PLATE Ø 27 cm**5626027
Ø 27 x H 3 cm

12 PC / 24 CTN



__ **DINNER PLATE Ø 24 cm**5626024
Ø 24 x H 3 cm
12 PC / 24 CTN



__ DINNER PLATE Ø 18 cm 5626018 Ø 18 x H 2 cm 12 PC / 36 CTN



__ PLATE Ø 25 cm 5626325 Ø 25 x H 3 cm 4 PC / 16 CTN



__ BOWL Ø 12 cm 5626112 Ø 12 x H 5 cm 12 PC / 36 CTN



__ BOWL Ø 12 cm 5626012 Ø 12 x H 6 cm 12 PC / 48 CTN



__ BOWL Ø 10 cm 5626010 Ø 10 x H 4 cm 12 PC / 48 CTN



__ **BOWL Ø 8 cm**5626008
Ø 8 x H 3,2 cm
12 PC / 48 CTN



__ PLATE Ø 21 cm 5626321 Ø 21 x H 3 cm 4 PC / 16 CTN



__ **SOUP PLATE Ø 26 cm**5626126
Ø 26 x H 5 cm
6 PC / 24 CTN



__ SOUP PLATE Ø 24 cm 5626124 Ø 24 x H 5 cm 6 PC / 12 CTN



__ **SOUP PLATE Ø 21 cm**5626121
Ø 21 x H 5 cm
6 PC / 24 CTN



__ APERO BOWL

5626206
6 x H 4 cm
18 PC / 72 CTN



__ APERO DISH 5626211 11 x H 4 cm 18 PC / 72 CTN



__ APERO DISH 5626210 10 x H 2 cm 12 PC / 96 CTN



__ APERO DISH 5626209 9 x H 4 cm 12 PC / 48 CTN

21



— PRESENTATION PLATE
Ø 25 cm
5626025
Ø 25 x H 3 cm
3 PC / 12 CTN



__ SERVING TRAY
5626129
29 x H 5 cm
6 PC / 24 CTN



__ BOWL Ø 16 cm 5626116 Ø 16 x H 7 cm 12 PC / 24 CTN



__ BOWL Ø 14 cm 5626014 Ø 14 x H 6 cm 8 PC / 32 CTN



ETNA



__ **DINNER PLATE Ø 28 cm**5694015
Ø 28 x H 3 cm
4 PC / 8 CTN



— DINNER PLATE Ø 25 cm5694014
Ø 25 x H 3 cm
4 PC / 8 CTN



__ **DESSERT PLATE Ø 20 cm**5694013
Ø 20 x H 3 cm

4 PC / 18 CTN



__ BREAD PLATE Ø 15 cm 5694012 Ø 15 x H 2 cm

4 PC / 48 CTN



__ SOUP PLATE Ø 19 cm 5694010 Ø 19 x H 6 cm - 800ml 4 PC / 16 CTN



__ **SOUP PLATE Ø 16 cm**5694016
Ø 16 x H 4 cm
6 PC / 24 CTN



— **SOUP BOWL Ø 11 cm**5694022
Ø 11 x H 5 cm - 250ml
6 PC / 48 CTN



__ BOWL Ø 7 cm 5694017 Ø 7 x H 4 cm - 75ml 12 PC / 144 CTN





__ RECTANGULAR PLATE

5694019
30 x H 3 cm
6 PC / 18 CTN



__ OVAL PLATE 5694018 35 x H 4 cm 3 PC / 12 CTN



— PRESENTATION PLATE
Ø 30 cm
5694003
Ø 30 x H 5 cm
2 PC / 12 CTN



___ **DISH**5694021
8 x H 4 cm
12 PC / 96 CTN



__ **SAUCER Ø 16 cm**5694009
Ø 16 x H 2 cm
12 PC / 36 CTN



__ **SAUCER Ø 12 cm**5694007
Ø 12 x H 2 cm
12 PC / 96 CTN



__ MUG Ø 9 cm 5694005 Ø 9 x H 11 cm - 400ml 6 PC / 24 CTN



PRESENTATION PLATE Ø 30 cm 5694002

3 PC / 9 CTN



— PRESENTATION PLATE
Ø 30 cm
5694004
Ø 30 x H 4 cm
3 PC / 9 CTN



— PASTA PLATE Ø 30 cm 5694001 Ø 30 x H 6 cm - 350ml 3 PC / 9 CTN



— **SOUP PLATE Ø 23 cm**5694011
Ø 23 x H 7 cm - 1560ml
2 PC / 12 CTN



__ COFFEE CUP Ø 9 cm 5694008 Ø 9 x H 6 cm - 220ml 6 PC / 36 CTN



ESPRESSOCUP Ø 7 cm5694006
Ø 7 x H 4 cm - 70ml
12 PC / 96 CTN



__ MILK JUG 5694023 11 x H 7 cm - 140ml 6 PC / 72 CTN





GRAY



__ **DINNER PLATE Ø 27 cm**5638027
Ø 27 x H 2 cm

6 CTN



— DINNER PLATE Ø 17 cm5638017
Ø 17 x H 2 cm
12 CTN



__ PLATE
5638036
36 x H 3 cm
6 CTN



__ PLATE
5638030
30 x H 3 cm
6 CTN



— PASTA PLATE Ø 29 cm 5638029 Ø 29 x H 5 cm - 430ml 6 CTN



__ **SOUP PLATE Ø 25 cm**5638025
Ø 25 x H 5 cm
6 CTN



__ BOWL Ø 16 cm 5638016 Ø 16 x H 7 cm - 540ml 4 CTN



__ BOWL Ø 11 cm 5638011 Ø 11 x H 8 cm - 270ml 6 CTN



___BOWL 5638007 6 x H 5 cm - 70ml 12 CTN



__ **SAUCER Ø 16 cm**5638116
Ø 16 x H 3 cm
12 CTN



__ COFFEE CUP Ø 9 cm 5638020 Ø 9 x H 7 cm - 200ml 12 CTN



__ MILK JUG Ø 6 cm 5638107 Ø 6 x H 4 cm - 70ml 12 CTN



BLUE



__ DINNER PLATE Ø 27 cm 5636027 Ø 27 x H 2 cm 6 CTN



__ DINNER PLATE Ø 17 cm 5636017 Ø 17 x H 2 cm 12 CTN



__ PLATE 5636036 36 x H 3 cm 6 CTN



__ PLATE 5636030 30 x H 3 cm 6 CTN



__ PASTA PLATE Ø 29 cm 5636029 Ø 29 x H 5 cm - 430ml 6 CTN



__ SOUP PLATE Ø 25 cm 5636025 Ø 25 x H 5 cm 6 CTN



__ BOWL Ø 16 cm 5636016 Ø 16 x H 7 cm - 540ml 4 CTN



__ BOWL Ø 11 cm 5636011 Ø 11 x H 8 cm - 270ml 6 CTN



__ BOWL 5636007 6 x H 5 cm - 70ml 12 CTN



__ SAUCER Ø 16 cm 5636116 Ø 16 x H 3 cm 12 CTN



__ COFFEE CUP Ø 9 cm 5636020 Ø 9 x H 7 cm - 200ml 12 CTN



__ MILK JUG Ø 6 cm 5636107 Ø 6 x H 4 cm - 70ml 12 CTN

32

ARTISAN

WHITE



— **DINNER PLATE Ø 27 cm**5639027
Ø 27 x H 2 cm
6 CTN



— DINNER PLATE Ø 17 cm5639017
Ø 17 x H 2 cm
12 CTN



— PLATE
5639036
36 x H 3 cm
6 CTN



__ PLATE
5639030
30 x H 3 cm
6 CTN



— PASTA PLATE Ø 29 cm 5639029 Ø 29 x H 5 cm - 430ml 6 CTN



__ **SOUP PLATE Ø 25 cm**5639025
Ø 25 x H 5 cm
6 CTN



__ BOWL Ø 16 cm 5639016 Ø 16 x H 7 cm - 540ml 4 CTN



__ BOWL Ø 11 cm 5639011 Ø 11 x H 8 cm - 270ml 6 CTN



___BOWL 5639007 6 x H 5 cm - 70ml 12 CTN



__ **SAUCER Ø 16 cm**5639116
Ø 16 x H 3 cm
12 CTN



__ COFFEE CUP Ø 9 cm 5639020 Ø 9 x H 7 cm - 200ml 12 CTN




__ MILK JUG Ø 6 cm 5639107 Ø 6 x H 4 cm - 70ml 12 CTN

33

12 CIN 12 CIN 12 CIN 12 CIN

BLACK





__ **DINNER PLATE Ø 27 cm**5634027
Ø 27 x H 2 cm



— DINNER PLATE Ø 17 cm5634017
Ø 17 x H 2 cm
12 CTN



— PLATE 5634036 36 x H 3 cm 6 CTN



__ PLATE
5634030
30 x H 3 cm
6 CTN



— PASTA PLATE Ø 29 cm 5634029 Ø 29 x H 5 cm - 430ml 6 CTN



__ **SOUP PLATE Ø 25 cm**5634025
Ø 25 x H 5 cm
6 CTN



__ BOWL Ø 16 cm 5634016 Ø 16 x H 7 cm - 540ml 4 CTN



__ BOWL Ø 11 cm 5634011 Ø 11 x H 8 cm - 270ml 6 CTN



___ BOWL 5634007 6 x H 5 cm - 70ml 12 CTN



__ **SAUCER Ø 16 cm**5634116
Ø 16 x H 3 cm
12 CTN



__ COFFEE CUP Ø 9 cm 5634020 Ø 9 x H 7 cm - 200ml 12 CTN



__ MILK JUG Ø 6 cm 5634107 Ø 6 x H 4 cm - 70ml 12 CTN



CREAM



— DINNER PLATE Ø 27 cm
5635027
Ø 27 x H 2 cm
6 CTN



__ DINNER PLATE Ø 17 cm
5635017
Ø 17 x H 2 cm
12 CTN



__ PLATE
5635036
36 x H 3 cm
6 CTN



— PLATE 5635030 30 x H 3 cm 6 CTN



— PASTA PLATE Ø 29 cm 5635029 Ø 29 x H 5 cm - 430ml 6 CTN



__ **SOUP PLATE Ø 25 cm**5635025
Ø 25 x H 5 cm
6 CTN



__ BOWL Ø 16 cm 5635016 Ø 16 x H 7 cm - 540ml 4 CTN



__ BOWL Ø 11 cm 5635011 Ø 11 x H 8 cm - 270ml 6 CTN



___ BOWL 5635007 6 x H 5 cm - 70ml 12 CTN



__ **SAUCER Ø 16 cm**5635116
Ø 16 x H 3 cm
12 CTN




__ COFFEE CUP Ø 9 cm 5635020 Ø 9 x H 7 cm - 200ml 12 CTN



__ MILK JUG Ø 6 cm 5635107 Ø 6 x H 4 cm - 70ml 12 CTN






SOLAS

BLUE



__ **DINNER PLATE Ø 27 cm**5631270
Ø 27 x H 2 cm
12 CTN



__ DINNER PLATE Ø 24 cm 5631024 Ø 24 x H 2 cm 12 CTN



__ **DESSERT PLATE Ø 21 cm**5631021
Ø 21 x H 2 cm
12 CTN



___ PLATE
5631228
29 x H 2 cm
12 CTN



— PLATE5631224
25 x H 2 cm
12 CTN



___ PLATE
5631219
21 x H 2 cm
24 CTN



__ **SOUP PLATE Ø 24 cm**5631124
Ø 24 x H 4 cm
6 CTN



__ **SOUP PLATE Ø 19 cm**5631119
Ø 19 x H 4 cm
12 CTN



__ MUG Ø 8 cm 5631027 Ø 8 x H 9 cm - 270ml 24 CTN



ESPRESSOCUP Ø 6 cm5631106
Ø 6 x H 6 cm - 90ml
48 CTN



__ BOWL Ø 14 cm 5631014 Ø 14 x H 8 cm 8 CTN



__ BOWL Ø 10 cm 5631010 Ø 10 x H 6 cm 18 CTN



__BOWL Ø 8 cm 5631008 Ø 8 x H 5 cm 18 CTN



— ESPRESSO SAUCER Ø
15 cm
5631115
Ø 15 x H 2 cm
48 CTN



SOLAS

MUSTARD



__ **DINNER PLATE Ø 27 cm**5405270
Ø 27 x H 2 cm
12 CTN



__ DINNER PLATE Ø 24 cm 5405024 Ø 24 x H 2 cm 12 CTN



__ **DESSERT PLATE Ø 21 cm**5405021
Ø 21 x H 2 cm
12 CTN



__ PLATE Ø 0 cm 5405228 29 x H 2 cm 12 CTN



— PLATE Ø 0 cm 5405224 25 x H 2 cm 12 CTN



__ PLATE Ø 0 cm 5405219 21 x H 2 cm 24 CTN



__ **SOUP PLATE Ø 24 cm**5405124
Ø 24 x H 4 cm
6 CTN



— **SOUP PLATE Ø 19 cm**5405119
Ø 19 x H 4 cm
12 CTN



__ BOWL Ø 14 cm 5405014 Ø 14 x H 8 cm 8 CTN



ESPRESSO SAUCER Ø15 cm
5405115
Ø 15 x H 2 cm
48 CTN



__ ESPRESSOCUP Ø 6 cm 5405106 Ø 6 x H 6 cm - 90ml 48 CTN

NOTES



